

PARTS LIST

AHT2630D-S

CONTENTS

1. MAIN BODY	1 ~ 2
2. GEARCASE	3 ~ 6
3. ENGINE	7 ~ 10
4. CARBURETOR, FUEL TANK	11 ~ 12
5. ACCESSORIES	13 ~ 14


2016. 12.



MARUYAMA


P/N 524182-2

1. AHT2630D-S
MAIN BODY




Ref. No.	Part No.	Part Name	Q'ty	Remarks
1-1	364569	AHT2630D-S	1	
1-2	219602	Clutch Case Ass'y	1	Incl.3-5
1-3	219465	Clutch Case	1	
1-4	016405	Bearing	1	#6200ZZ
1-5	013825	Snap Ring	1	#30
1-6	261246	Cap Screw	1	M5x25
1-7	229091	Clutch Drum	1	
1-8	224679	Driveshaft Tube	1	24xt1.6x723
1-9	224680	Driveshaft Ass'y	1	
1-10	235078	Throttle Trigger	1	
1-11	215533	Hanging Bracket Ass'y	1	Incl.12
1-12	261762	Cap Screw	1	M5x14
1-13	215350	Cap	1	
1-14	238134	Label	1	AHT2630D
1-15	237626	Label	1	CE
1-16	231468	Label	1	
1-17	261250	Cap Screw	4	M5x20
1-18	231955	Loop Handle Ass'y	1	Incl.19-21
1-19	225699	Loop Handle	1	
1-20	081027	Nut	4	M5
1-21	215608	Cap Screw	4	M5x30x16

2. AHT2630D-S
GEARCASE




Ref. No.	Part No.	Part Name	Q'ty	Remarks
2-1	237090	Trimmer Ass'y	1	Incl.2-61
2-2	407312	Joint Case	1	
2-3	631779	Joint	1	
2-4	407313	Bearing	2	
2-5	631757	Snap Ring	2	RTW26
2-6	407314	Bevel Gear	1	
2-7	407315	Cover	1	
2-8	580766	Grease Nipple	1	M6
2-9	631753	Screw	2	M4x8
2-10	407316	Gearcase	1	
2-11	407317	Crankshaft	1	
2-12	407318	Bevel Gear	1	
2-13	631759	Snap Ring	1	STW28
2-14	582443	Bearing	1	#6000 2RS
2-15	580766	Grease Nipple	2	M6
2-16	631755	Snap Ring	1	ETW6
2-17	407319	Shaft	1	
2-18	407320	Cover	1	
2-19	407321	Screw	1	M6x16
2-20	631749	Spring Washer	1	M6
2-21	582436	Washer	1	M6
2-22	407322	Bearing	1	
2-23	631753	Screw	2	M4x8
2-24	407323	Bearing	2	
2-25	407324	Snap Ring	1	
2-26	407325	Bevel Gear	1	
2-27	407326	Blade	2	
2-28	407327	Guide Plate	1	
2-29	237226	Blade Guard	1	
2-30	580764	U-Nut	6	M6
2-31	631765	Screw	3	L17
2-32	631764	Screw	2	L19
2-33	407328	Screw	1	L26
2-34	991913	Washer	6	
2-35	407329	Low Case	1	
2-36	631771	Bearing	1	#608 2RS
2-37	407330	Handle	1	
2-38	407331	Bolt	4	M5x14
2-39	631778	Cap Screw	1	M5x25
2-40	631777	Cap Screw	1	M5x12
2-41	407332	Felt	1	
2-42	407333	Plate	1	
2-43	407334	Bolt	1	M5x16
2-44	407335	Cover of Blade	1	
2-45	407336	Screw	1	M6x12

2. AHT2630D-S
GEARCASE




Ref. No.	Part No.	Part Name	Q'ty	Remarks
2-46	407337	Knob	1	
2-47	407338	Washer	2	
2-48	407339	Spring	1	
2-49	631770	Screw	1	M6x12
2-50	631749	Spring Washer	1	M6
2-51	582436	Washer	1	M6
2-52	407340	Plate	1	
2-53	407341	Bolt	1	M6x25
2-54	407342	Lever	1	
2-55	407343	Bush	1	
2-56	407344	Spring	1	
2-57	646471	Washer	1	
2-58	407345	Bolt	1	M5x8
2-59	407347	Plate	1	
2-60	407348	Washer, Wave	2	
2-61	407349	Label	1	

3. AHT2630D-S ENGINE




Ref. No.	Part No.	Part Name	Q'ty	Remarks
3-1	859839	Engine	1	EE262/01
3-2	273153	Cylinder	1	
3-3	282330	Gasket	1	
3-4	261250	Cap Screw	4	M5x20
3-5	282579	Insulator	1	
3-6	267049	Gasket	1	
3-7	269826	Screw	2	M5x25
3-8	276315	Muffler Ass'y	1	
3-9	266402	Cap Screw	2	M5x55
3-10	273147	Gasket	1	
3-11	273618	Under Cover	1	
3-12	269827	Screw	1	M5x16
3-13	276319	Top Cover	1	
3-14	280144	Tapping Screw	1	
3-15	273673	Crankcase	1	
3-16	280488	Bearing	2	PPL 6001
3-17	261492	Oil Seal	1	ISCD12287
3-18	261386	Oil Seal	1	ISCD12227
3-19	055185	Snap Ring	1	#28
3-20	261612	Cap Screw	3	M5x30
3-21	273155	Piston	1	
3-22	261496	Piston Ring	2	(2)Required
3-23	261497	Piston Pin	1	
3-24	261037	Bearing,Needle	1	KBK8x11x11.8x1
3-25	261576	Clip,Piston	2	
3-26	282323	Crankshaft/Conn.Rod Ass'y	1	
3-27	269168	Clutch Ass'y	1	Incl.28,29
3-28	269169	Clutch Shoe	2	(2)required
3-29	269173	Spring, Clutch	1	
3-30	269647	Clutch Bolt	2	
3-31	269175	Washer	2	6.1x15x1.6
3-32	261777	Wave Washer	2	
3-33	283386	Fan Cover	1	
3-34	269831	Screw	4	M5x20
3-35	282692	Magneto Ass'y	1	Incl.36-42
3-36	261356	Rotor/Fan	1	
3-37	282693	Ignition Coil Ass'y	1	Incl.38-42
3-38	267401	Coil	1	
3-39	282694	Spark Plug Wire Ass'y	1	Incl.40-42
3-40	261074	Plug Boot	1	
3-41	261075	Connector	1	
3-42	282695	Spark Plug Wire	1	
3-43	261076	Woodruff Key	1	3x10
3-44	261417	Nut,Rotor	1	M8
3-45	280381	Spacer	2	

3. AHT2630D-S ENGINE












Ref. No.	Part No.	Part Name	Q'ty	Remarks
3-46	261256	Cap Screw	2	M4x25
3-47	288264	Spark Plug	1	BPMR8Y
3-48	267492	Lead	1	130L
3-49	282880	Wire, Lead	1	
3-50	288684	Recoil Starter Ass'y	1	Incl.51-59
3-51	288685	Starter Ass'y	1	Incl.52-58
3-52	288967	Reel	1	
3-53	288968	Spiral Spring	1	
3-54	262922	Screw	1	
3-55	288969	Starter Rope Ass'y	1	Incl.56-58
3-56	288970	Starter Rope	1	
3-57	261725	Starter Grip	1	
3-58	283511	Rope Stopper	1	
3-59	288971	Starter Pawl Ass'y	1	
3-60	269833	Screw	1	M4x16
3-61	280489	Screw	2	M4x20
3-62	276312	Label	1	
3-63	284587	Label	1	
3-64	286122	Label	1	MARUYAMA

4. AHT2630D-S
 CARBURETOR, FUEL TANK



Ref. No.	Part No.	Part Name	Q'ty	Remarks
4-1	276328	Carburetor Ass'y	1	Incl.2-15
4-2	281597	Pump Body	1	
4-3	262991	Purge Body	1	
4-4	262992	Cover Plate	1	
4-5	261874	Primer Bulb	1	
4-6	283905	Diaphragm, Meterring	1	
4-7	262993	Gasket	1	
4-8	262994	Diaphragm,Fuel Pump	1	
4-9	282576	Gasket	1	
4-10	285030	Main Jet	1	
4-11	261871	O-Ring	1	
4-12	261876	E-Ring	1	
4-13	261658	Swivel	1	
4-14	264682	Screw	2	
4-15	262996	Screw	4	
4-16	261864	Gasket	1	
4-17	289048	Case Ass'y	1	Incl.18-24
4-18	269050	Case Body	1	
4-19	289019	Valve	1	
4-20	284803	Lever	1	
4-21	284816	Washer	1	6.4x11x0.15
4-22	269032	Screw	1	
4-23	126993	Nut	1	M5
4-24	269051	Sleeve	2	
4-25	269030	Element	1	
4-26	281777	Screw	2	M5x55
4-27	269580	Cleaner Cover	1	
4-28	269031	Screw	1	M5x12
4-29	276310	Fuel Tank Ass'y	1	Incl.30-40
4-30	273467	Fuel Tank	1	
4-31	275306	Fuel Tank Cap Ass'y	1	Incl.32
4-32	274875	Gasket	1	
4-33	261696	Breather Ass'y	1	
4-34	265752	Fuel Pipe Pick-up Ass'y	1	Incl.35-40
4-35	264031	Fuel Pipe Ass'y	1	Incl.36-38
4-36	261115	Grommet	1	
4-37	261690	Fuel Pipe	1	160L
4-38	263038	Return Pipe	1	3x6x85L
4-39	264653	Filter Ass'y	1	
4-40	261117	Clip	1	
4-41	261117	Clip	1	
4-42	269828	Screw	2	M5x16
4-43	281208	Screw	1	M5x16

5. AHT2630D-S
ACCESSORIES



Ref. No.	Part No.	Part Name	Q'ty	Remarks
5-1	210418	Box Spanner	1	13x19x(+)
5-2	022865	Double-ended Wrench	1	8x10
5-3	219432	Wrench	1	4mm
5-4	234954	Colgate Tube	1	60L
5-5	234955	Band	1	3.4x145L
5-6	238138	Instruction Manual	1	GB/IT/FR
5-7	238139	Instruction Manual	1	ES/PT/DE
5-8	238140	Instruction Manual	1	GR/PL/RO
5-9	238141	Instruction Manual	1	NL/HR
5-10	524182	Parts List	1	AHT2630D-S