


# Exploded Parts List of Pole with Chainsaw



**Part list KM0408235 (With chainsaw head)**

NO	NAME	QTY	NO.	NAME	QTY	NO.	NAME	QTY
1	Engine	1	41	Holder	1	81	Support spring	2
2	Cover	1	42	Screw	4	82	Bearing	2
3	Bearing	1	43	Cup	1	83	Cover	1
4	Stop ring	1	44	Screw	2	84	Sheath	1
5	Cover	1	45	Shim	2	85	Cover	2
6	Washer	1	46	Cap	1	86	Rod linker	2
7	Screw	1	47	Plug	1	87	Pin	2
8	Fastener	1	48	Washer	1	88	Button	1
9	Stop ring	1	49	Linker	1	89	Clamp	1
10	Link	1	50	Bearing	1	90	Stop ring	1
11	Nut	4	51	Chain	1	91	--	
12	--	1	52	Stop ring	1	92	Button	
13	--		53	Key	1	93	Spring	
14	Flexible shaft	1	54	Guide bar	1	94	--	
15	Right handle shell	1	55	Shaft	1	95	Strap hook	1
16	Nut	7	56	Worm wheel	1	96	--	
17	--		57	Chain cover	1	97	--	
18	--		58	Washer		98	Left handle shell	
19	--		59	Screw	1	99	Rod	
20	Belt	1	60	Bolt	1	100	Screw	5
21	Handle front	1	61	Cover board	1	101	Clamp	1
22	Switch	1	62	Washer	1	102	Screw	4
23	Screw ST	1	63	Screw	1	103	Pump seat	
24	Spring ring	1	64	Chain wheel	1			
25	Handle spring	1	65	--				
26	Handle	1	66	Seat	1			
27	Washer	5	67	Washer	1			
28	Link board	1	68	Bearing	1			
29	Washer		69	Oil pipe	1			
30	Nail	2	70	Wheel	1			
31	Bearing	8	71	Oil wheel	1			
32	Pipe		72	Spring	1			
33	Bearing bracket	4	73	Ring	1			
34	Pipe	1	74	Pin	1			
35	--	1	75	Ring	1			
36	Inner pipe	1	76	Oil seal	1			
37	Linker	1	77	Oil pump	1			
38	Bearing	2	78	Screw	2			
39	Gear	1	79	Pump nozzle	1			
40	Oil container	1	80	Nozzle	1			

